



ASSEMBLY INSTRUCTION


BISTRO ROUND DINING TABLE

This page lists the contents included in the box. Please take time to identify the hardware as well as the individual components of the product . As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage. Please follow the assembly instructions closely. Improper assembly can result in personal or property damage



HARDWARE

A




X-4 ALLEN BOLTS
(M8 x 50MM)

B




X-4 WASHER
(M8 x 25MM)

C




X-1 ALLEN KEY
(5 MM)

PRODUCT PARTS




X-01 TABLE TOP





X-01 BASE

①



②



X - 04

ASSEMBLY IS NOW COMPLETE

Cleaning & Care

Clean surface with a dry soft cloth. Do not use abrasive or oil based cleaners. Furniture wax can be used, as this items has already been finished with a natural wax over a protective clear lacquer. It is recommended to use coasters to protect surface from heat and water. Periodically check and tighten hardware as necessary.