
Assembly Instruction and Safety Guide




Redang Inflatable Lounger
Article number: 9906-222 / 9905-222

Thank you for purchasing this product!



Scan the QR code to access
instructions in your language



FR

Donnez ou recyclez
vos meubles.



Association

ou



Magasin



Déchèterie

<https://quefairedemesdechets.fr>



Package Contents

- 1 Olefin fabric cover
- 1 Inflatable PVC bag
- 1 Electric pump



Important Safety Warnings

- This product is **not a life-saving device**
- For recreational use only
- Do not use in open water, strong currents, or ocean
- Do not use under the influence of alcohol or drugs
- Do not jump or dive onto or from the lounger
- Maximum weight: [Insert kg/lbs]
- Always check the product for damage before use
- **Do not puncture the inflatable bag**
- **Do not use sharp objects on the lounger**
- **Do not allow children to play on the inflatable lounger**
- **Keep away from fire**

Assembly and Inflation Instructions

1. Remove the fabric cover and the inflatable PVC bag from the packaging.

2. Insert the inflatable PVC bag into the fabric cover.


Align the valve with the cover opening:

- Top valve = inflation (1)
- Bottom valve = deflation (2)

3. Connect the electric pump to the top valve and inflate to the appropriate level. **Do not overinflate.**

4. Once inflated, close the zipper to cover the valve and adjust the chair position.

5. The inflatable lounger is now ready for use.



Electric Pump – Specifications and Safety

Model: JY-019

Specifications:

- Voltage: 220–240 V
- Frequency: 50/60 Hz
- Power: Max 150 W
- Protection Class: IP00
- For indoor and household use only

Explanation of Symbols

- **CE** – Product complies with EU safety requirements.
- **UKCA** – Product complies with UK safety requirements.
- **WEEE** – Electrical components must be disposed of at an authorized recycling facility.
- **Double square** – Class II insulation (double insulation, no earth connection required).



Warnings:

- To reduce the risk of electric shock, do not expose the pump to rain or moisture.
- Store the pump indoors.
- Do not operate the pump for more than 10 minutes continuously.
- Connect the pump directly to a suitable power outlet.
- Do not use the pump if the cord or housing is damaged.
- Keep the pump out of reach of children.
- Never insert fingers or objects into the pump openings.
- Use only the recommended electric inflation equipment.

Maintenance and Care

- Clean the inflatable bag with fresh water after use
- Allow to air dry completely before storage
- Store in a dry place away from direct sunlight
- Regularly check seams and valves for leaks or damage

Disposal

- Electrical components must be disposed of at an authorized recycling facility (WEEE symbol).
- Follow local regulations for waste disposal.

Cover Washing Instructions:

-  Machine wash max 30 °C
-  Do not bleach
-  Dry in shade
-  Do not iron
-  Do not dry clean

Warranty and Contact

Warranty period: See purchase documentation or contact customer service.

Country of Manufacture: China

Contact / Kontakt / Kontaktinformation

Manufacturer / Hersteller / Tillverkare: Venture Design AB

Address / Adresse / Adress: Deltavägen 12, 352 45 Växjö, Sweden

Phone / Telefon / Telefon: +46 (0)470-554000

Email / E-Mail / E-post: info@venturedesign.se

Website / Webseite / Webbplats: www.venturedesign.se