

Assembly Instruction




WARNING: To avoid serious personal injury:

- Carefully and strictly follow assembly instructions. Improper assembly of furniture can result in structural failure, instability of the product, or tip-over.
- Monitor and carefully control the assembly components. These include small parts and hardware that may present a choking hazard to small children. And furniture should be assembled only by responsible adults and children should not be involved in the assembly process.
- Where provided, wall mounting hardware should always be used as prescribed in these instructions to anchor furniture to walls. Proper use of the wall mounting hardware can significantly reduce the potential for furniture tip-over and crushing injuries.

Part Details


A		1PC
B		2PCS
C		2PCS
D		1PC
E		2PCS

Step 1




Fix one side of the L-shaped device at the bottom middle position of the side of the console table against the wall.

Step 2




Place the console table in the desired position and mark the hole position of the fixing device on the wall.

Step 3



Drive expansion screws into the marked positions on the wall.

Step 4



Place the console table against the wall and tighten the remaining two screws of the L-shaped device.